

Pioneer CU-F002 F-757

Key (Button)	Format	Code	
		Customer	Data
POWER	NEC	A45B	1CE3
MPX NR			51AE
SSS			52AD
MPX MODE			1EE1
DOWN			57A8
UP			56A9
BAND			13EC
1			01FE
2			02FD
3			03FC
4			04FB
5			05FA
6	06F9		
7	07F8		
8	08F7		
9	09F6		
10	00FF		
11	46B9		
12	47B8		

Pioneer CU-F003 F-777

Key (Button)	Format	Code	
		Customer	Data
POWER	NEC	A45B	1CE3
MPX NR			51AE
SSS			52AD
MPX MODE			1EE1
DOWN			57A8
UP			56A9
BAND			13EC
1			01FE
2			02FD
3			03FC
4			04FB
5			05FA
6			06F9
7			07F8
8			08F7
9			09F6
0/10			00FF
CLASS			40BF
MEMORY SCAN	4DB2		